




Deadbolt Door Marking Template



Preparing Door & Frame

Necessary for new doors or adjusting existing prep.





Check Your Door Guide

For doors with existing hardware

Keyed Locks




*Keyed locks are supplied with Screw Set D for 1-3/4" to 2-1/4" door thickness. A thin door gasket (sold separately) is required for 1-3/8" to 1-3/4" door thicknesses. Screw Sets B and C cannot be used.

Key Free Locks



*Key Free locks are supplied with all screw sets to accommodate door thicknesses 1-3/8" to 2-1/4".





- A. Minimum clearance between top of existing lever/knob rose (trim) and center of deadbolt hole.
- * B. 1-3/8" Door Thickness; use Screw Set B for key free locks or thin gasket for keyed locks. Screws are tinted green.
- * C. 1-3/8" 1-3/4" Door Thickness; use Screw Set C for key free locks or thin gasket for keyed locks. Screws are tinted black.
- * D. 1-3/4" 2-1/4" Door Thickness; use Screw Set D. Screws are tinted silver.
- E. Backset; use Out of Box latch setting.
- F. Backset; adjust latch setting.
- G. Face Bore Diameter.
- H. Edge Bore Diameter and Depth. Cross Bore Diameter.


CAUTION: ed from elect


If printed from electronic file, set print scale to 1:1 Measure ruler to check scale.


Measure Clearance ✓ Greater than A X Less than A (Your door is not a match for a Yale electronic lock)











Yale Locks & Hardware

Product Support Tel 1-855-213-5841 • www.yalehome.com

Yale® is a registered trademark of ASSA ABLOY Residential Group. Other products' brand names may be trademarks or registered trademarks of their respective owners and are mentioned for reference purposes only. © Copyright 2020. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Residential Group is prohibited.